






Поз	Наименование детали
1	Toast tray
2	Crumb may
3	Toast rack
4	Front panel
5	Power switch
6	Function knob
7	Speed knob
8	Spring ring
9	Inner cover plate
10	Control panel
11	Function switch
12	Knob base
13	PCB
14	Foot pad
15	Screw
16	Foot
17	Bottom plate
18	Connector stator
19	Connector
20	Chain
21	Front blocking plate
22	Left inner plate
23	Toast tray stator
24	Crumb tray stator
25	Chain stator
26	Axle pin
27	Heating element stator
28	Inner wire
29	E shape buckle
30	Axle sleeve
31	Spindle stator
32	Screw
33	Schain wheel
34	Spingle
35	Gear base
36	Chain gear
37	Screw
38	Heating element
39	Right inner plate
40	Power cord stator
41	Power cord base
42	ower motor base
43	DC motor
44	Motor support base
45	Temperaature resistant cotton
46	Cotton stator
47	Big gear
48	Small gear
49	Power cord
50	Upper inner plate
51	Temperaature resistant cotton
52	Left housing
53	Spindle
54	Screw
55	Back barricade
56	Back inner plate
57	Upper housing
58	Right inner huusing